

BASIN

Item No.	Code No.	Part No.	Description	Item No.	Code No.	Part No.	Description
1.	38730002	STB-3000	RECT. CTR TOP BASIN	11.	38730013	STB-3050	OVAL VESSEL CTR TOP BASIN
2.	38730003	STB-3005	OVAL CTR TOP BASIN W/TAP HOLE	12.	38730014	SWB-3055	RECT. WALL MOUNT CTR TOP BASIN
3.	38730004	STB-3010	DESIGNER CTR TOP BASIN	13.	38730015	SUB-3060	OVAL UNDER CTR BASIN
4.	38730005	STB-3015	SOFT RECT. CTR TOP BASIN	14.	38730016	SUB-3070	RECT. UNDER CTR BASIN
5.	38730006	STB-3020	SOFT SQ. CTR TOP BASIN	15.	38730017	SWB-3075	DEEP RECT WALL MOUNT CTR TOP BASIN
6.	38730007	STB-3025	SOFT SQ. CTR TOP BASIN W/TAP HOLE	16.	38730021	STB-3080	RECT. CTR TOP BASIN W/TAP HOLE
7.	38730008	STB-3030	SQUARE CTR TOP BASIN	17.	38730022	SWB-3085	SOFT RECT. WALL MOUNT BASIN
8.	38730009	STB-3035	ROUND CTR TOP BASIN	18.	38730023	SWB-3090	OVAL VESSEL WALL MOUNT BASIN
9.	38730011	STB-3040	TRIANGULAR CTR TOP BASIN	19.	38730046	SUB-3095	RECT UNDER CTR BASIN O/F HOLE
10.	38730012	STB-3045	OVAL WIDE CTR TOP BASIN				

TROUBLE SHOOTING GUIDE

- Check for any leaks or damages in pipes and plumbing.
- Always test your cleaning solution on an inconspicuous area before applying to the entire surface.
- Avoid using any harsh chemicals or acids to clean the taps or faucets as they can permanently damage the parts being cleaned.
- Use a soft, dampened sponge or cloth. Never use an abrasive material such as a brush or scouring pad to clean surfaces

